

sl1s File Management

What can go wrong when setting up sl1s file?

- zip-folder not correctly set up, e.g. it contains a subfolder. Solution: Do not select the folder itself, but select all content of the folder and send to zipped folder. Then rename to .sl1s
- config.ini or prusaslicer.ini are missing
- pictures must have five-digit numbers starting at 00000
- 'numFast' in config.ini has to match total number of pictures, i.e. last picture has number numFast-1 because it starts at zero
- image names in front of the numbers has to be the same as 'jobDir' in config.ini

Idea: "sl1s Sanitizer" checking a selected sl1s file if it meets all the above criteria and throws descriptive errors if not.

- use python (or matlab)
- use a git repository!